Overview and Key Functions of Executive Telephone (e.g. 97901)



Overview and Functions of the Secretary Telephone (e.g. 97900)

15 08 Mo 10.11.08 97900 Image: Comparison of the second	Personal line key <personal telephone<br="">number>: - Only displays status, no further functionality</personal>
97901 Chef Um. Chef ein Um. Chef aus Shift	Press this key to call Executive telephone: Status symbols: - Light on -> Executive line is in use - Light blinking -> Exectuive line is being called Further functions: - Connect call to Executive line - Receive call ringing at Executive line
15 09 Mo 10.11.08 97900 □ Übersicht [Mein Telefon] 97900 97900 → 97901 Chef •	Key Um. Chef ein: - Allows you to redirect all incoming calls for the Executive to the Secretary line.
DSS:97901 Leitung umgelei Um. Chef ein Um. Chef aus	Key Um. Chef aus: - Allows you to turn off call redirecting from Executive to Secretary.
Shift	In the default screen view, the Secretary telephone does not show whether call redirection is turned on or off. By switching to the tab "Übersicht," you can see the status of the Executive's line as well as whether call redirection is turned on.